


A4 PAPER SIZE

Note: Print page at 100%



Teapot Cosy

↓
Add 1 inch to lower
edge when cutting out
↓